



Figure 93. Crankshaft and Oil Pump.

(1) ITEM NO.	(2) FSCM	(3) PART NUMBER	(4) DESCRIPTION AND USABLE ON CODE	(5) QTY
			GROUP 16 AIR COMPRESSOR ASSEMBLY	
			FIG. 93 CRANKSHAFT AND OIL PUMP	
1	2K654	75A51	SCREW, CAP	4
2	2K654	2010243	COVER	1
3	2K654	77G34	SHIM SET	2
4	2K654	2012919	PUMP, OIL	1
5	2K654		SPACER	1
6	2K654		GEAR	1
7	2K654		CAM	1
8	2K654		HOUSING, PUMP OIL	1
9	2K654	2010244	PLUNGER	1
10	2K654	2010245	SPRING	1
11	2K654	75A12	SCREW, CAP	8
12	2K654	200AVL006	PLATE, END	1
13	2K654	77B34	SHIM SET	1
14	2K654	25C2068	GASKET RING	1
15	2K654	12C28	BEARING, ROLLER W/CASE	2
16	2K654	200AVL004	CRANKSHAFT	1
17	2K654	60G41	SEAL, OIL	1
			END OF FIGURE	