

4834-091

Figure 91. Pistons, Connecting Rods and Bearings, Low Pressure

| (1) ITEM | (2) | (3) PART | (4) | (5) |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------|
| NO. | FSCM | NUMBER | DESCRIPTION AND USABLE ON CODE | QTY |
| 1 2 3 4 5 6 7 8 9 10 11 2 3 4 5 6 7 8 9 10 11 2 3 4 5 6 7 8 9 10 11 2 3 4 5 6 7 8 9 10 | 2K654 2K654 2K654 2K654 2K654 2K654 2K654 2K654 2K654 2K654 2K654 2K654 | 75A130 ADL8 25C1882 ACR557 50M 11 VAB381 2012481 200ADL174 97A29 75E11 62F63 200AVL003B ACL15 65V16 65S30 | GROUP 16 AIR COMPRESSOR ASSEMBLY FIG. 91 PISTON, CONNECTING RODS, AND BEARINGS, LOW PRESSURE CAP, SCREW PLATE, INSPECTION OIL GASKET GAGE, OIL LEVEL ROD NUT, LOCK NUT ROD BOLTS, CONNECTING WITH NUT BEARING, HALVES WIRE, LOCK, 12 IN SCREW, CAP PIN, PISTON ROD, CONNECTING AND BEARING, CAP PISTON, AIR, LOW PRESSURE RING, OIL, LOW PRESSURE RING, OIL, LOW PRESSURE END OF FIGURE | 4 1 1 1 4 2 2 2 1 1 1 1 1 3 1 |